


# INSTALLATION GUIDE



## **XR100 SERIES CANADIAN CONTROL PANEL**

# **MODEL XR100 SERIES CANADIAN CONTROL PANEL INSTALLATION GUIDE**

## **INDUSTRY CANADA NOTICE**

This Class A digital apparatus complies with Canadian ICES-003.

© 2015 Digital Monitoring Products, Inc.

Information furnished by DMP is believed to be accurate and reliable.  
This information is subject to change without notice.

---

## Product Specifications

1.1	Power Supply .....	1
1.2	Communication .....	1
1.3	Panel Zones .....	1
1.4	Keypad Bus .....	1
1.5	LX-Bus™ .....	1
1.6	Outputs .....	1
1.7	Enclosure Specifications .....	1

## Panel Features

2.1	Description.....	1
2.2	Zone Expansion .....	2
2.3	Output Expansion .....	2
2.4	Central Station Communication .....	2
2.5	Caution Notes .....	2
2.6	Compliance Instructions .....	2

## System Components

3.1	Description.....	2
3.2	Wiring Diagram .....	3
3.3	Lightning Protection.....	3
3.4	Accessory Devices .....	4
3.4	Accessory Devices (continued).....	5

## Installation

4.1	Mounting the Enclosure.....	6
4.2	Mounting Keypads and Zone Expansion Modules.....	7
4.3	Connecting LX-Bus and Keypad Bus Devices .....	7
4.4	Wireless Keypad Association .....	7

## Primary Power Supply

5.1	AC Terminals 1 and 2 .....	8
5.2	Transformer Types .....	8
5.3	J12 3-Pin Header for Transformer Types .....	8

## Secondary Power Supply

6.1	Battery Terminals 3 and 4 .....	9
6.2	Earth Ground (GND) .....	9
6.3	Battery Only Restart .....	9
6.4	Battery Replacement Period.....	9
6.5	Discharge/Recharge.....	9
6.6	Battery Supervision.....	9
6.7	Battery Cutoff.....	9
6.8	XR100 Series Canadian Power Requirements .....	10
6.9	Standby Battery Selection .....	12

## Bell Output

7.1	Terminals 5 and 6.....	13
-----	------------------------	----

## Keypad Bus

8.1	Description.....	13
8.2	Terminal 7 - RED .....	13
8.3	Terminal 8 - YELLOW .....	13
8.4	Terminal 9 - GREEN .....	13
8.5	Terminal 10 - BLACK .....	13
8.6	J8 Programming Connection .....	13
8.7	OVC LED.....	13

## Smoke and Glassbreak Detector Output

9.1	Terminals 11 and 12 .....	13
9.2	Current Rating.....	13

# TABLE OF CONTENTS

## Protection Zones

10.1	Terminals 13–24 .....	14
10.2	Dual EOL .....	14
10.3	Zone Response Time.....	14
10.4	Keyswitch Arming Zone .....	14

## Powered Zones for 2-Wire Smoke Detectors

11.1	Terminals 25–26 and 27–28 .....	14
11.2	Compatible 2-Wire Smoke Detector Chart.....	15

## Dry Contact Relay Outputs

12.1	Description.....	16
12.2	Contact Rating .....	16
12.3	Model 431 Output Harness Wiring.....	16

## Annunciator Outputs

13.1	Description.....	16
13.2	Model 300 Harness Wiring.....	16
13.3	Model 860 Relay Module .....	16

## J23 6-Pin Header

14.1	Description.....	17
------	------------------	----

## J22 LX-Bus Expansion Connector

15.1	Description.....	17
15.2	J22 LX-Bus Header .....	17
15.3	LX-Bus Interface Cards.....	17
15.4	LX-Bus LEDs.....	17
15.5	OVC LED.....	17

## J1 Ethernet Connector (XR100N only)

16.1	Description.....	18
16.2	Ethernet LEDs .....	18

## J3 Telephone RJ Connector

17.1	Description.....	18
17.2	J10 893A Connector.....	18
17.3	Notification .....	18
17.4	Phone Line Monitor .....	18

## Reset and Tamper Headers

18.1	J16 Reset Header .....	19
18.2	J4 Tamper Header .....	19

## Listed Compliance Specifications

19.1	Introduction .....	20
------	--------------------	----

## Burglary Specifications

20.1	Introduction .....	20
20.2	Control Outside of Protected Area .....	20
20.3	Bypass Reports.....	20
20.4	System Maintenance .....	20

## ULC S304-06 Specifications

21.1	For Low Risk Applications: Level A1 .....	20
21.2	For Low Risk Applications: Level P1.....	20
21.3	Dual Protection.....	20
21.4	Remote Arming .....	20
21.5	Zone Expansion .....	20

## ULC S559-04 Specifications

22.1	For Fire Communicator Applications .....	21
22.2	Central Station Host Automation .....	21

## Recommendations

23.1	ULC Installation Recommendations .....	21
------	--	----

## False Alarm Reduction Programmable Options \*

24.1	Shipping Defaults and Recommended Programming or ANSI/SIA CP-01-2010 .....	22
24.2	Call Waiting (ANSI/SIA CP-01-2010).....	23
24.3	Occupied Premise (ANSI/SIA CP-01-2010).....	23
24.4	Entry Delay (ANSI/SIA CP-01-2010).....	23
24.5	Minimum Installation Requirements (ANSI/SIA CP-01-2010) ....	23

## Wiring Diagrams

25.1	LX-Bus™ Module Connection .....	24
25.2	Model 860 Relay Module Connection .....	25
25.3	Dual Zone Protection .....	25
25.4	Canadian Fire Communicator for FACP .....	26
25.5	Combination S304 and S559 System .....	27
25.6	System Sensor 2-Wire Smoke Detectors .....	28

## Revisions to This Document

This page intentionally left blank

## Product Specifications

### 1.1 Power Supply

Transformer Input: Model 327-CAN, plug-in — Primary input: 120 Vac, 60 Hz, Secondary output: 16.5 Vac 50 VA  
Model FTA7516 ATC Frost from Standex Electronics — Primary input: 120 Vac, 60 Hz,  
Secondary output: 16 Vac 75 VA

Standby Battery: 12 Vdc, 1.0 Amps Max. charging current  
Models 365, 366, 368, or 369  
Replace every 3 to 5 years

Auxiliary: 12 Vdc output at 1.0 Amp Max using Model 327-CAN

Bell Output: 12 Vdc at 1.0 Amp Max using Model 327-CAN

Auxiliary: 12 Vdc output at 1.5 Amp Max using Model FTA7516

Bell Output: 12 Vdc at 1.5 Amp Max using Model FTA7516

All circuits are inherent Power Limited except the red battery wire and AC terminal.

### 1.2 Communication

- Built-in network communication to DMP Model SCS-1R or SCS-VR Receivers (XR100N only)
- Built-in encrypted communication to DMP Model SCS-1R Receivers
- Built-in Contact ID communication to DMP Model SCS-1R Receivers
- Optional cellular communication to DMP Model SCS-1R or SCS-VR Receivers
- Can operate as a local panel

### 1.3 Panel Zones

Eight 1k Ohm EOL burglary zones (zones 1 to 8)

Two 3.3k Ohm EOL powered zone with reset (zones 9 and 10)

### 1.4 Keypad Bus

You can connect up to a total of eight of the following supervised keypads and expansion modules to the keypad bus:

- Alphanumeric keypads
- Single-zone detectors
- Wireless Keypads (maximum of 4)
- Four- and/or single-zone expansion modules
- Access control modules

### 1.5 LX-Bus™

You can connect the following devices to the LX-Bus™ provided on the panel or by the DMP 481, 462N and 464-263H Interface Cards up to the maximum number of LX-Bus™ addresses. See Accessory Devices in section 3.4.

- Sixteen-, eight-, four- and/or single-zone expansion modules
- Model 521LX or 521LXT Smoke Detectors with CleanMe
- Model 2W-BLX or 2WT-BLX Smoke Detectors
- Graphic annunciator modules
- Relay output expansion modules

### 1.6 Outputs

The XR100 Series provide two Single Pole, Double Throw (SPDT) relay outputs which require the installation of two Model 305 relays, each rated 1 Amp at 30 Vdc resistive (power limited sources only). A Model 431 Output Harness is required to use these outputs.

The XR100 Series also provide four open collector outputs rated for 50mA each. The open collector outputs provide ground connection for a positive voltage source. A Model 300 Output Harness is required to use these outputs.

### 1.7 Enclosure Specifications

The XR100 Series are shipped in an enclosure with a transformer, End-of-Line resistors, battery leads, user's guide, and programming sheets.

Enclosure Model	Size	Color(s)	Construction (Cold Rolled Steel)
350	17.5"W x 13.5"H x 3.5"D	Gray (G) or Red (R)	18-Gauge
350A	17.5"W x 13.5"H x 3.75"D	Gray (G)	18-Gauge with 16-Gauge door
341	12.45"W x 6.55"H x 3.15"D	Gray (G)	20-Gauge

## Panel Features

### 2.1 Description

The DMP XR100 Series Canadian panel is a versatile 12 Vdc, combined access control, burglary, and fire communicator panel with battery backup. The XR100 Series provides eight on-board burglary zones and two on-board 12 Vdc Class B powered zones. The powered zones have a reset capability to provide for 2-wire smoke detectors, relays, or other latching devices. The XR100 Series can communicate to DMP SCS-1R Receivers using digital dialer, cellular, network, or Contact ID communication.

# INTRODUCTION

## 2.2 Zone Expansion

Up to 142 additional zones are available on the XR100 Series using DMP LCD keypad remote zone capability and zone expansion modules. The panel keypad data bus supports up to eight supervised device addresses with each address supporting up to four programmable expansion zones.

Up to 100 zones are available using the on board LX-Bus, Model 481, 462N and 464-263H, and any combination of single, four, eight, or 16-zone expansion modules and single-zone LX-Bus™ detectors.

**Note:** Do not use shielded wire for LX-Bus or Keypad Bus circuits.

## 2.3 Output Expansion

In addition to the two SPDT relays and four programmable open collector outputs on the XR100 Series, you can also connect up to 25 programmable Model 716 Output Expansion Modules. These modules can provide an additional 100 programmable SPDT relays.

The XR100 Series provides 100 Output Schedules for programming the 716 to perform a variety of annunciation and control functions. Also assign the 716 outputs to any panel Output Options such as Fire Alarm, Communication Fail, or Phone Trouble Outputs. Refer to the 716 Installation Guide (LT-0183).

The LX-Bus™ also supports the Model 717 Graphic Annunciator Module. Each 717 module supplies 20 switched ground outputs that follow the state of their assigned zones.

**Note:** The 717 supports the first eight Keypad Bus addresses. Refer to the 717 Installation Guide (LT-0235) and 716 Installation Guide (LT-0183).

## 2.4 Central Station Communication

Program the XR100 Series panel for reporting to DMP SCS-1R or SCS-VR Receivers using digital dialer, cellular, network, or Contact ID communication. The XR100 Series connects at the premises to a standard RJ31X or RJ38X telephone jack. Use the DMP 893A Dual Phone Line Module when connecting the XR100 Series panel to two separate phone lines.

## 2.5 Caution Notes

Throughout this guide you will see caution notes containing information you need to know when installing the panel. These cautions are indicated with a yield sign. Whenever you see a caution note, make sure you completely read and understand its information. Failing to follow the caution note can cause damage to the equipment or improper operation of one or more components in the system. See the example shown below.



**Always ground the panel before applying power to any devices:** The panel must be properly grounded before connecting any devices or applying power to the panel. Proper grounding protects against Electrostatic Discharge (ESD) that can damage system components.

## 2.6 Compliance Instructions

For applications that must conform to a local authorities installation standard or a National Recognized Testing Laboratory certificated system, please see the Listed Compliance Specifications section near the end of this guide for additional instructions.

# System Components

## 3.1 Description

The DMP XR100 Series system is made up of an alarm panel with a built-in communicator, an enclosure, battery, one 16.5 Vac transformer, and keypads. You can use up to sixteen supervised 32-character LCD keypads; network communications; zone and output expansion modules; and initiating and indicating circuit modules. You can also connect auxiliary devices to the panel's output relays to expand the basic system control capability. Combined current requirements of additional modules may require an auxiliary power supply. Refer to the XR100 Series Power Requirements section in this guide when calculating power requirements.





# INTRODUCTION

## 3.4 Accessory Devices

<b>Interface Card</b>	
462N Network Interface Card	Allows you to connect the XR100 Series to any compatible data network and use its communication capability in place of standard dial out telephone lines. The 462N also provides an LX-Bus™ for connecting zone and output expansion modules to the panel.
464-263H Cellular Communicator Card	Provides a fully supervised alarm communication path over HSPA + network for XR100/ XR500 Series panels. The 464-263H also provide an LX-Bus™ for connecting zone and output expansion modules to the panel.
481 Expansion Interface Card	Provides one LX-Bus for connecting up to 100 zone and output expansion modules.
<b>Expansion Modules</b>	
710 Bus Splitter/Repeater*	Allows you to increase keypad or LX-Bus™ wiring distance to 2500 feet.
711 Single Point Zone Expanders	Provides one Class B zone for connecting burglary devices.
714, 714-8, 714-16 Zone Expanders	Provides Class B zones for connecting burglary and non-powered fire devices.
712-8 Zone Expander	Provides Class B zones for connecting burglary devices.
715, 715-8, 715-16 Zone Expanders	Provides 12 Vdc Class B powered zones for connecting smoke detectors, glassbreak detectors, and other 2- or 4-wire devices.
716 Output Expander	Provides four Form C relays (SPDT) and four switched grounds (open collector) for use in a variety of remote annunciation and control applications for use on the LX-Bus only.
717 Graphic Annunciator Module*	Provides 20 zone following annunciator outputs (open collector) for use in a variety of remote annunciation and control applications for use on the LX-Bus only.
734, 734N, 734N-WiFi Wiegand Interface Modules*	Provides system codeless entry, and arming and disarming using access control readers.
<b>DMP Two-Way Wireless Devices</b>	
1100X/1100XH Wireless Receiver*	Supports up to 100 devices in residential or commercial wireless operation.
1100R Repeater*	Provides additional range for wireless devices.
1101 Universal Transmitter*	Provides both internal and external contacts that may be used at the same time to yield two individual reporting zones from one wireless transmitter.
1102 Universal Transmitter*	Provides an external contact.
1103 Universal Transmitter*	Provides both internal and external contacts that may be used at the same time to yield two individual reporting zones from one wireless transmitter. Requires EOL resistor for external contact. Provides Disarm/Disable functionality.
1105 Universal Transmitter*	Provides both internal and external contacts that may be used at the same time to yield two individual reporting zones from one wireless transmitter.
1107 Micro Window Transmitter*	Provides a window transmitter and magnet
1114 Four-Zone Expander*	Provides four wireless zones
1116 Relay Output*	Provides one Form C relay
1117 LED Annunciator*	Provides a visual system status indicator
1118 Remote Indicator Light*	Provides a visual indication of a Panic situation
1119 Door Sounder*	Provides a battery powered sounder
1121 PIR Motion Detector*	Provides motion detection with pet immunity.
1125 PIR Motion Detector*	Provides multiple lens configurations, dual coverage area selection, and sensitivity adjustments.
1126C/1126R PIR Motion Detector*	Ceiling mount motion detector with panel programmable sensitivity and Disarm/Disable functionality.
1127C/1127W PIR Motion Detector*	Wall mount motion detector with panel programmable sensitivity and Disarm/Disable functionality.
1129 Glassbreak Detector*	Detects the shattering of framed glass mounted in an outside wall and provides full-pattern coverage and false-alarm immunity.
<b>* These devices have not been investigated and shall not be used in commercial burglary installations</b>	

### 3.4 Accessory Devices (continued)

<b>DMP Two-Way Wireless Devices</b>	
1131 Recessed Contact*	Provides a recessed contact option for door or window applications.
1135/1135DB Wireless Sirens*	Provides a wireless siren.
1139 Bill Trap*	Provides a silent alarm option for retail and banking cash drawers.
1142BC Two-button Hold-up Belt Clip Transmitter*	Provides portable two-button hold-up operation.
1142 Two-button Hold-up Transmitter*	Provides permanently mounted under-the-counter two-button hold-up operation.
1145-4 (Four-Button)* 1145-2 (Two-Button)* 1145-1 (One-Button)*	Key Fob transmitters designed to clip onto a key ring or lanyard.
1184 Carbon Monoxide Detector*	Carbon monoxide detector
<b>Indicating and Initiating Devices</b>	
860 Relay Module*	Provides dry relay contacts that are programmable and controlled from the DMP panel annunciator outputs. Includes one Form C (SPDT) relay rated 1 Amp @ 30 Vdc. Sockets are provided to allow the addition of three Model 305 plug-in relays. These relays can be used for electrical isolation between the alarm panel and another system or switching 5, 12, or 24 Volts to control various functions within a building or around its perimeter.
865 Supervised Style W or X Notification Circuit Module*	Provides supervised alarm current when using the XR500 Series panel bell output and up to 5 Amps at 12 or 24 Vdc when using a listed auxiliary power supply. The 865 can supervise 2-wire or 4-wire style circuits for opens and shorts with individual LED annunciation.
866 Style W Notification Circuit Module*	Provides supervised alarm current using the XR100 Series panel bell output and up to 5 Amps at 12 or 24 Vdc when using a listed auxiliary power supply. The 866 can supervise 2-wire Style W circuits for opens and shorts.
867 Style W LX-Bus Notification Circuit Module*	Provides supervised alarm current using the XR100 Series panel bell output and up to 5 Amps at 12 or 24 Vdc when using a listed auxiliary power supply. The 867 connects to the XR100 Series panel LX-Bus™ and provides one 2-wire Style W notification circuit for ground faults, open and short conditions. Individual Bell Relay addresses Bell Ring styles.
869 Dual Class A Style D Initiating Module*	Provides two Class A, Style D, 4-wire initiating zones for connecting waterflow switches and other non-powered fire and burglary devices.
<b>Accessory Modules and Keypads</b>	
893A Dual Phone Line Module*	Allows you to supervise two standard phone lines connected to an XR100 Series panel. The 893A module monitors the main and backup phone lines for a sustained voltage drop and alerts users when the phone line is bad.
ePAD™ Mobile Keypad*	Allows users to control the security system from any computer in the world using the Internet.
LCD keypads	Allows you to control the panel from various remote locations. Connect up to sixteen Model 630F Remote Fire Command Center, Model 7060, 7063, 7070, 7073, 7160, 7163, 7170, 7173 Thinline™ keypads, 7060A, 7063A, 7070A, 7073A Aqualite™ keypads, or the 7872, 7873 Graphic Touchscreen keypads to the keypad bus using terminals 7, 8, 9, and 10.
9000 Series Wireless Keypad*	Allows you to control the panel from various remote locations. Connect up to four 9060/9063 Wireless Keypads.
<b>Addressable Smoke Detectors</b>	
521LX, 521LXT*	Single-zone, addressable conventional smoke, smoke/heat detectors that connect to the LX-Bus. Includes remote maintenance reporting, drift compensation, and multi-criteria detection.
2W-BLX, 2WT-BLX*	Single-zone, addressable conventional smoke, smoke/heat detectors that connect to the LX-Bus. Includes drift compensation.
<b>* These devices have not been investigated and shall not be used in commercial burglary installations</b>	

## Installation

### 4.1 Mounting the Enclosure

The metal enclosure for the XR100 Series must be mounted in a secure, dry place to protect the panel from damage due to tampering or the elements. It is not necessary to remove the XR100 Series PCB when installing the enclosure. Figure 2 shows the mounting hole locations for both the Model 350/350A Enclosures. Figure 3 shows the Model 341 Kiosk Enclosure.

The 350A Attack Resistant enclosure is factory shipped with one knockout on the top left of the enclosure. As needed, additional knockouts or antenna exits may be added at the time of installation. See Figure 2 for the positions on the enclosure that can be added. Each additional knockout must be filled with conduit.

**Note:** When using the XR100 Series panel for listed applications, use the Model 350, 349, 341, or 352S enclosure for standby batteries. When using the 352S in listed applications, the enclosure must be surface mounted on the wall.




Figure 2: XR100 Series in Model 350 or 350A Enclosure




Figure 3: XR100 Series in Model 341 Enclosure

## 4.2 Mounting Keypads and Zone Expansion Modules

DMP LCD keypads have removable covers that allow you to easily mount the keypad to a wall or other flat surface using the screw holes on each corner of the base. Before mounting the base, connect the keypad wire harness leads to the keypad cable from the panel and to any device wiring run to that location. Then attach the harness to the pin connector on the PC board, mount the base, and install the keypad cover making sure all of the keys extend through their respective holes.

For mounting keypads on solid walls, or for applications where conduit is required, use the Model 695 1-1/2" deep or the Model 696 1/2" deep backboxes.

The DMP 711, 712-8, 714, 715, 716, and 717 modules are each contained in molded plastic housings with removable covers. The base provides you with mounting holes for installing the unit to a wall, switch plate, or other surface.

## 4.3 Connecting LX-Bus and Keypad Bus Devices

Several factors determine the DMP LX-Bus™ and keypad bus performance characteristics: the wire length and gauge used, the number of devices connected, and the voltage at each device. When planning an LX-Bus™ and keypad bus installation, keep in mind the following information:

1. DMP recommends using 18 or 22-gauge **unshielded** wire for all keypad and LX-Bus circuits. **Do not** use twisted pair or shielded wire for LX-Bus and keypad bus data circuits. All 22-gauge wire must be connected to a power-limited circuit and jacket wrapped.
2. On keypad bus circuits, to maintain auxiliary power integrity when using 22-gauge wire do not exceed 500 feet. When using 18-gauge wire do not exceed 1,000 feet. To increase the wire length or to add devices, install an additional power supply that is listed for Fire Protective Signaling, power limited, and regulated (12 Vdc nominal) with battery backup.  
**Note:** Each panel allows a specific number of supervised keypads. Add additional keypads in the unsupervised mode. Refer to the panel installation guide for the specific number of supervised keypads allowed.
3. Maximum distance for any one bus circuit (length of wire) is 2,500 feet regardless of the wire gauge. This distance can be in the form of one long wire run or multiple branches with all wiring totaling no more than 2,500 feet. As wire distance from the panel increases, DC voltage on the wire decreases. Maximum number of LX-Bus devices per 2,500 feet circuit is 40.
4. Maximum voltage drop between the panel (or auxiliary power supply) and any device is 2.0 Vdc. If the voltage at any device is less than the required level, add an auxiliary power supply to the circuit. When voltage is too low, the devices cannot operate properly.

For additional information refer to the LX-Bus/Keypad Bus Wiring Application Note (LT-2031).

## Expansion Interface Cards (Models 481, 462N and 464-263H)

The LX-Bus provided on these cards requires only a 4-wire cable between the card and any devices connected to the bus. You can connect devices (zone or output expansion modules) together on the same cable or provide separate runs back to the card. The LX-Bus provides up to 100 zones or outputs.

**Note:** Do not use twisted pair or shielded wire when connecting an LX-Bus or keypad bus.


## 4.4 Wireless Keypad Association

Enable Wireless Keypad Association operation on both the keypad and panel.

To enable association operation in the keypad, access the Installer Options Menu (3577 (INST)) and select RF Survey). The keypad logo LEDs turn on Red until association is successful.

To enable association operation in the XR100 panel, reset panel 3 times within 12 seconds. Allow the keypad bus Transmit/Receive LEDs to turn back on between each reset.

For 60 seconds the panel listens for wireless keypads that are in the Installer Options Menu (3577 CMD) and have not been programmed, or associated into another panel. Those keypads are assigned to the first open device position automatically based upon the order in which they are detected. The keypad logo turns Green to indicate it has been associated with the panel.



## Primary Power Supply

### 5.1 AC Terminals 1 and 2

Connect the transformer wires to terminals 1 and 2 on the panel. Use no more than 70 ft. of 16 gauge or 40 ft. of 18 gauge wire between the transformer and the XR100 Series.



***Always ground the panel before applying power to any devices:*** The XR100 Series must be properly grounded before connecting any devices or applying power to the panel. Proper grounding protects against Electrostatic Discharge (ESD) that can damage system components. See Earth ground section 6.2.

### 5.2 Transformer Types

Use Model 327-CAN (16.5 Vac 50 VA) plug-in or Model FTA7516 from ATC Frost.



The transformer must be connected to an unswitched 120 Vac 60 Hz electrical outlet with at least .87A of available current. ***Never share the transformer output with any other equipment.***

### 5.3 J12 3-Pin Header for Transformer Types

Place the jumper on the left two pins for a Maximum 2 Amp (Bell=1 Amp; Aux=1 Amp) when using the Model 327-CAN plug-in transformer (default).

Use an ATC Frost FTA7516 transformer and place the jumper on the right two pins for a Maximum, 3 Amps (Bell=1.5 Amp; Aux=1.5 Amp).



## Secondary Power Supply

### 6.1 Battery Terminals 3 and 4

Connect the black battery lead to the negative battery terminal. The negative terminal connects to the enclosure ground internally through the XR100 Series circuit board. Connect the red battery lead to the battery positive terminal. Observe polarity when connecting the battery.

You can add a second battery in parallel using the DMP Model 318 Dual Battery Harness. **DMP requires each battery be separated by a PTC in the battery harness wiring to protect each battery from a reversal or short within the circuit. See Figure 4.**



**Use sealed lead-acid batteries only:** Use the DMP Model 365 (12 Vdc 9 Ah), Model 366 (12 Vdc 18 Ah), Model 368 (12 Vdc 5.0 Ah), or Model 369 (12 Vdc 7 Ah) sealed lead-acid rechargeable battery. Batteries supplied by DMP have been tested to ensure proper charging with DMP products.

GEL CELL BATTERIES CANNOT BE USED WITH THE XR100 SERIES PANEL.

### 6.2 Earth Ground (GND)

To provide proper transient suppression, XR100 Series panel terminal 4 must be connected to earth ground using 14 gauge or larger wire. DMP recommends connecting to a cold water pipe, ground rod, or building ground only. Do not connect to an electrical ground or conduit, sprinkler or gas pipes, or to a telephone company ground.

### 6.3 Battery Only Restart

When powering up the XR100 Series panel without AC power, briefly short across the battery start pads to pull in the battery cutoff relay. The leads need a momentary short only. Once the relay has pulled in, the battery voltage holds it in that condition. If the XR100 Series panel is powered up with an AC transformer, the battery cutoff relay is pulled in automatically. For more information refer to Figure 1.

### 6.4 Battery Replacement Period

DMP recommends replacing the battery every 3 to 5 years under normal use.

### 6.5 Discharge/Recharge

The XR100 Series battery charging circuit float charges at 13.9 Vdc at a maximum current of 1.0 Amps using a 50 VA or 56 VA transformer. Listed below are the various battery voltage level conditions:

Battery Trouble:	Below	11.9 Vdc
Battery Cutoff:	Below	10.2 Vdc
Battery Restored:	Above	12.6 Vdc

### 6.6 Battery Supervision

The XR100 Series tests the battery when AC power is present. The test is done every three minutes and lasts for five seconds. During the test, the panel places a load on the battery; if the battery voltage falls below 11.9 Vdc a low battery is detected. If AC power is not present, a low battery is detected any time the battery voltage falls below 11.9 Vdc. If a low battery is detected with AC power present, the test repeats every two minutes until the battery charges above 12.6 Vdc indicating the battery has restored voltage. If a weak battery is replaced with a fully charged battery, the restored battery will not be detected until the next two minute test is completed.

### 6.7 Battery Cutoff

The panel disconnects the battery any time the battery voltage drops below 10.2 Vdc. This prevents battery deep discharge damage.




Figure 6: Wiring Multiple Batteries

## 6.8 XR100 Series Canadian Power Requirements

During AC power failure, the XR100 Series panel and all connected auxiliary devices draw their power from the battery. All devices must be taken into consideration when calculating the battery standby capacity. The following table lists the XR100 Series panel power requirements. You must add the additional current draw of keypads, zone expansion modules, smoke detector output, and any other auxiliary devices used in the system for the total current required. The total is then multiplied by the number of standby hours required to calculate the total ampere-hours required.

Standby Battery Power Calculations	Standby Current			Alarm Current		
XR100 Series Control Panel	Qty <u>1</u>	180mA	180 mA	Qty <u>1</u>	180mA	180 mA
Relay Outputs 1-2 (ON)	Qty _____	30mA	_____	Qty _____	30mA	_____
Switch Grounds 3-6 (ON)	Qty _____	5mA	_____	Qty _____	5mA	_____
Active Zones 1-8	Qty _____ x	1.6mA	_____	Qty _____ x	2mA*	_____
Active Zones 9-10	Qty _____	4mA	_____	Qty _____	30mA	_____
2-Wire Smoke Detectors	Qty _____	0.1mA	_____	Qty _____	0.1mA	_____
Panel Bell Output					1500mA	_____ mA
893A Dual Phone Line Module	Qty _____ x	12mA	_____	Qty _____ x	50mA	_____
462N Network Interface Card	Qty _____ x	50mA	_____	Qty _____ x	50mA	_____
481 Expansion Interface Card	Qty _____ x	15mA	_____	Qty _____ x	15mA	_____
464-263H HSPA+ Cellular Communicator	Qty _____ x	15mA	_____	Qty _____ x	48mA	_____
1100X Wireless Receiver	Qty _____ x	46mA	_____	Qty _____ x	46mA	_____
1100XH Wireless High Power Receiver	Qty _____ x	160mA	_____	Qty _____ x	160mA	_____
860 Relay Output Module (one relay active)	Qty _____ x	34mA	_____	Qty _____ x	34mA	_____
All four relays active		138mA	_____		138mA	_____
865 Style W or X Notification Module	Qty _____ x	26mA	_____	Qty _____ x	85mA	_____
866 Style W Notification Module	Qty _____ x	45mA	_____	Qty _____ x	76mA	_____
867 LX-Bus Style W Notification Module	Qty _____ x	30mA	_____	Qty _____ x	86mA	_____
869 Dual Style D Initiating Module	Qty _____ x	25mA	_____	Qty _____ x	75mA	_____
7060/7160 Thinline/7060A Aqualite Keypad	Qty _____ x	72mA	_____	Qty _____ x	80mA	_____
7063/7163 Thinline/7063A Aqualite Keypad	Qty _____ x	85mA	_____	Qty _____ x	100mA	_____
7070/7170 Thinline/7070A Aqualite Keypad	Qty _____ x	72mA	_____	Qty _____ x	87mA	_____
Active Zones (EOL Installed)	Qty _____ x	1.6mA	_____	Qty _____ x	2mA*	_____
7073/7173 Thinline/7073A Aqualite Keypad	Qty _____ x	85mA	_____	Qty _____ x	100mA	_____
Active Zones (EOL Installed)		1.6mA	_____		2mA*	_____
7872 Graphic Touchscreen Keypad	Qty _____ x	145mA	_____	Qty _____ x	215mA	_____
Active Zones (EOL Installed)	Qty _____ x	1.6mA	_____	Qty _____ x	2.0mA	_____
7873 Graphic Touchscreen Keypad	Qty _____ x	143mA	_____	Qty _____ x	243mA	_____
Active Zones (EOL Installed)	Qty _____ x	1.6mA	_____	Qty _____ x	2.0mA	_____
734 Wiegand Interface Module	Qty _____ x	15mA	_____	Qty _____ x	15mA	_____
Active Zones (EOL Installed)	Qty _____ x	1.6mA	_____	Qty _____ x	2mA*	_____
Annunciator (ON)				Qty _____ x	20mA	_____
734N Wiegand Interface Module	Qty _____ x	146mA	_____	Qty _____ x	148mA	_____
Active Zones (EOL Installed)	Qty _____ x	1.6mA	_____	Qty _____ x	2mA*	_____
Annunciator (ON)				Qty _____ x	20mA	_____
Wiegand Reader	Qty _____ x	200mA	_____	Qty _____ x	200mA	_____
734N-WiFi Wiegand Interface Module	Qty _____ x	146mA	_____	Qty _____ x	148mA	_____
Active Zones (EOL Installed)	Qty _____ x	1.6mA	_____	Qty _____ x	2mA*	_____
Annunciator (ON)				Qty _____ x	20mA	_____
Wiegand Reader	Qty _____ x	200mA	_____	Qty _____ x	200mA	_____
<b>Copy Sub-Totals to next page</b>	Sub-Total Standby _____ mA			Sub-Total Alarm _____ mA		

\*Based on 10% of active zones in alarm.



Standby Battery Power Calculations	Standby Current	Alarm Current
736P POPIT Interface Module Radionics Popex, POPITs, OctoPOPITs	Qty _____ x 25mA _____ Qty _____ x _____mA _____	Qty _____ x 25mA _____ Qty _____ x _____mA _____
738A Ademco Wireless Interface Module	Qty _____ x 75mA _____	Qty _____ x 75mA _____
710 Bus Splitter/Repeater Module	Qty _____ x 32mA _____	Qty _____ x 32mA _____
711 Zone Expansion Module Active Zone (EOL Installed)	Qty _____ x 11mA _____ Qty _____ x 1.6mA _____	Qty _____ x 11mA _____ Qty _____ x 2mA* _____
714 Zone Expansion Module Active Zones (EOL Installed)	Qty _____ x 7mA _____ Qty _____ x 1.6mA _____	Qty _____ x 7mA _____ Qty _____ x 2mA* _____
712-8 Zone Expansion Module Active Zones (EOL Installed)	Qty _____ x 17mA _____ Qty _____ x 1.6mA _____	Qty _____ x 17mA _____ Qty _____ x 2mA* _____
714-8, 714-16 Zone Expansion Module Active Zones (EOL Installed)	Qty _____ x 20mA _____ Qty _____ x 1.6mA _____	Qty _____ x 20mA _____ Qty _____ x 2mA* _____
715 Zone Expansion Module Active Zones (EOL Installed) 2-Wire Smokes	Qty _____ x 7mA _____ Qty _____ x 4mA _____ Qty _____ x .1mA _____	Qty _____ x 7mA _____ Qty _____ x 30mA* _____ Qty _____ x .1mA _____
715-8, 715-16 Zone Expansion Modules Active Zones (EOL Installed) 2-Wire Smokes	Qty _____ x 20mA _____ Qty _____ x 4mA _____ Qty _____ x .1mA _____	Qty _____ x 20mA _____ Qty _____ x 30mA* _____ Qty _____ x .1mA _____
716 Output Expansion Module Active Form C Relays	Qty _____ x 13mA _____	Qty _____ x 13mA _____ Qty _____ x 12mA _____
717 Graphic Annunciator Module Annunciator Outputs	Qty _____ x 10mA _____	Qty _____ x 10mA _____ Qty _____ x 1mA _____
521LX, 521LXT Smoke Detectors	Qty _____ x 8.8mA _____	Qty _____ x 28mA* _____
2W-BLX, 2WT-BLX Smoke Detectors	Qty _____ x 15mA _____	Qty _____ x 36mA* _____
572 Indicator LED	Qty _____ x 20mA _____	Qty _____ x 20mA _____
Aux. Powered Devices on Terminals 7 and 11 Other than Keypads and LX-Bus Modules	_____ mA	_____ mA
<b>This page only</b>	Sub-Total Standby _____ mA	Sub-Total Alarm _____ mA
<b>Sub-Totals from previous page</b>	Sub-Total Standby _____ mA	Sub-Total Alarm _____ mA
*Based on 10% of active zones in alarm	Total Standby _____ mA	Total Alarm _____ mA
<p>Total Standby _____ mA x number of Standby Hours needed _____ = _____ mA-hours</p> <p>Total Alarm _____ mA + _____ mA-hours</p> <p>Total _____ mA-hours</p> <p>X .001</p> <p>= _____ Amp-hrs Required</p>		

Refer to section 6.9 for standby battery selection.

# INSTALLATION

## 6.9 Standby Battery Selection

To choose the type and number of batteries needed for 24, 60, or 72 hours of standby power based on the Amp Hours Required calculation from section 6.8 XR500 Series Power Requirements, perform the following:

1. Select the desired standby hours required from the table below: 24, 60, or 72 hours
2. Select the desired battery size: Model 368 (12 Vdc 5.0 Ah), Model 369 (12 Vdc 7 Ah), Model 365 (12 Vdc 9 Ah), Model 366 (12 Vdc 18 Ah).
3. Select a Max. Ah Available number that is just greater than the number calculated in Amp Hours Required.
4. Install the number of batteries shown in the corresponding No. of Batteries required column.

**Example:** If the Amp Hours Required calculation equals 22 Ah for 24 hours of standby time and 4.5 Ah batteries are desired, install six (6) Model 368 (12 Vdc, 5.0 Ah) batteries.

**Note:** You can use either a Model 327-CAN Plug-in 50 VA or ATC Frost FTA7516 75VA Transformer with any of the Number of Batteries choices listed below.

### 24 hours of standby power

5.0 Ah Batteries		7 Ah Batteries		7.7 Ah Batteries		9 Ah Batteries		18 Ah Batteries	
Max. Ah Available	No. of Batteries	Max. Ah Available	No. of Batteries	Max. Ah Available	No. of Batteries	Max. Ah Available	No. of Batteries	Max. Ah Available	No. of Batteries
8	2	6	1	6	1	8	1	16	1
12	3	12	2	13	2	16	2	32	2
16	4	18	3	20	3	24	3	48	3
20	5	24	4	27	4	32	4		
24	6	31	5	34	5	40	5		
28	7	37	6	41	6				
32	8	43	7						
36	9								
40	10								

**Note:** 48 hours is the typical battery recharge time for any of the Number of Batteries shown in this section.

### 60 hours of standby power

7 Ah Batteries		7.7 Ah Batteries		9 Ah Batteries		18 Ah Batteries	
Max. Ah Available	No. of Batteries	Max. Ah Available	No. of Batteries	Max. Ah Available	No. of Batteries	Max. Ah Available	No. of Batteries
13	2	14	2	17	2	17	1
20	3	22	3	26	3	34	2
27	4	29	4	34	4	52	3
33	5	37	5	43	5	69	4
40	6	44	6	52	6		
47	7	52	7	61	7		
54	8	59	8	69	8		
60	9	67	9				
67	10						

**Note:** 48 hours is the typical battery recharge time for any of the Number of Batteries shown in this section.

### 72 hours of standby power

9 Ah Batteries		18 Ah Batteries	
Max. Ah Available	No. of Batteries	Max. Ah Available	No. of Batteries
16	2	16	1
25	3	33	2
33	4	50	3
42	5	67	4
50	6		
59	7		
67	8		

**Note:** 72 hours is the typical battery recharge time required for any of the Number of Batteries shown in this section.

**Note:** If the Amp Hours Required calculation is greater than any Max. Ah Available number shown on a table, then add power supply(s) to power some system devices allowing the Amp Hours Required calculation to be reduced. See the 710 Bus Splitter/Repeater Installation Guide (LT-0310).

## **Bell Output**

### **7.1 Terminals 5 and 6**

Terminal 5 supplies positive 12 Vdc to power alarm bells or horns. This output can be steady, pulsed, or temporal depending upon the Bell Action specified in Output Options. Terminal 6 is the ground reference for the bell circuit. This supervised output detects 1k Ohms or less as normal. The indicating appliance can supply this resistance. If using a horn or siren, a 1k Ohm 1/2 W EOL resistor (provided) should be added across the bell circuit to provide supervision. See the Notification Appliance section for a list of approved notification appliances and the Wiring Diagrams for connections.

## **Keypad Bus**

### **8.1 Description**

XR100 Series panel terminals 7, 8, 9, and 10 are for the keypad bus. You can connect up to eight supervised keypads and multiple unsupervised keypads to the XR100 Series. In addition to DMP LCD keypads, you can also connect any combination of zone expansion modules to the data bus. Refer to the specific device installation sheet for the maximum number of keypad Bus devices.

Refer to the section titled LX-Bus for complete information about the LX-Bus 4-pin header and expansion slot.

**Note:** Do not use shielded wire for LX-Bus/Keypad Bus circuits.

### **8.2 Terminal 7 - RED**

This terminal supplies positive 12 Vdc regulated to power DMP LCD keypads and zone expansion modules. Terminal 7 also supplies power for any auxiliary device. The ground reference for terminal 7 is terminal 10.

The output current is shared with the smoke power output on terminal 11 and Zones 9 and 10. Current draw for all connected devices must not exceed the panel maximum current rating. See Power Supply in the Compliance section for maximum current in a fire listed application.

### **8.3 Terminal 8 - YELLOW**

Terminal 8 receives data from keypads and zone expansion modules. It cannot be used for any other purpose.

### **8.4 Terminal 9 - GREEN**

Terminal 9 transmits data to keypads and zone expansion modules. It cannot be used for any other purpose.

### **8.5 Terminal 10 - BLACK**

Terminal 10 is the ground reference for DMP LCD keypads, zone expansion modules, and all auxiliary devices being powered by terminal 7.

### **8.6 J8 Programming Connection**

A 4-pin header (J8) is provided to connect a keypad when using a DMP Model 330 Programming Cable. This provides a quick and easy connection for panel programming.

You may also use the J8 Programming Header to connect Keypad Bus devices. This is an alternative to connecting keypad bus devices to terminals 7, 8, 9, and 10.

### **8.7 OVC LED**

The Overcurrent LED (OVC) lights Red when the devices connected to the Keypad Bus and LX-Bus(es) draw more current than the panel rating. The OVC is located above Outputs 1 and 2 on the panel and turns a steady Red when lit. When the OVC LED lights Red, the LX-Bus(es) and Keypad bus are shut down.

## **Smoke and Glassbreak Detector Output**

### **9.1 Terminals 11 and 12**

Terminal 11 supplies positive 12 Vdc regulated to power 4-wire smoke detectors and other powered devices. This output can be turned off by the user for 5 seconds using the Sensor Reset User Menu option to allow latched devices to reset. Terminal 12 is the ground reference for terminal 11.

### **9.2 Current Rating**

The Output current from terminal 11 is shared with terminals 7, 25, and 27.



The total current draw of all devices powered from the panel must be included with terminal 11 calculations and must not exceed the maximum output rating.

## Protection Zones

### 10.1 Terminals 13–24

Zones 1 to 8 (terminals 13 to 24) on the XR100 Series panel are all grounded burglary zones. For programming purposes, the zone numbers are 1 through 8. Listed below are terminal 13 to 24 connection functions.

Terminal	Function	Terminal	Function
13	Zone 1 voltage sensing	19	Zone 5 voltage sensing
14	Ground for Zones 1 and 2	20	Ground for Zones 5 and 6
15	Zone 2 voltage sensing	21	Zone 6 voltage sensing
16	Zone 3 voltage sensing	22	Zone 7 voltage sensing
17	Ground for Zones 3 and 4	23	Ground for Zones 7 and 8
18	Zone 4 voltage sensing	24	Zone 8 voltage sensing

The voltage sensing terminal measures the voltage across a 1k Ohm End-of-Line resistor to ground. Use DMP Model 311 1k Ohm resistors. Dry contact sensing devices can be used in series (normally-closed) or in parallel (normally-open) with any of the burglary protection zones.

Each protection zone detects three conditions: Open, Normal, and Short. Listed below are voltage and resistance parameters for each condition:




Figure 5: Protection Zone Wiring

Condition	Resistance on zone	Voltage on positive terminal
Open	over 1300 ohms	over 2.0 Vdc
Normal	600 to 1300 ohms	1.2 to 2.0 Vdc
Short	under 600 ohms	under 1.2 Vdc


### 10.2 Dual EOL

The XR100 Series Canadian panel supports the use of dual 1K EOL resistors on panel zones one to eight. Two EOL resistors are used so a wire trouble can be indicated during the disarm period.

When dual end-of-line operation is chosen in panel programming, normal zone processing occurs with the following exception: When processing an open zone and a trouble or alarm message is NOT programmed to be sent for the open state, the panel checks to see if the wire is cut. If the wire is cut, the panel automatically sends an alarm if armed or trouble is disarmed.

#### ZONE STATUS

	Zone Wires Open	Zone Wires Short	Contact Normal	Contact Open
Disarmed	Trouble	Trouble	Normal	Normal
Armed	Alarm	Alarm	Normal	Alarm



### 10.3 Zone Response Time

A condition must be present on a zone for 500 milliseconds before it is detected by the XR100 Series panel. Ensure detection devices used on the protection zones are rated for use with this delay. Zones 1-10 can also be programmed for a fast response delay of 160 milliseconds.

### 10.4 Keyswitch Arming Zone

A keyswitch on an Arming type zone allows selected areas to arm and disarm without having to enter a user code.

## Powered Zones for 2-Wire Smoke Detectors

### 11.1 Terminals 25–26 and 27–28

Panel terminals 25 through 28 provide two resettable Class B, Style A, 2-wire powered zones. For programming purposes the zone numbers are 9 and 10.

**Note:** The maximum wire length for either zone 9 or zone 10 is 3000 feet using 18 AWG or 1000 feet using 22 AWG. The maximum voltage is 14 Vdc and maximum current is 1.25mA DC. The maximum line impedance is 100 Ohms. The maximum short circuit current is 56mA.

When using all other zone expansion modules, use UL Listed Model 309 EOL resistors. The compatibility identifier for the zones is A.

**Note:** Do not mix detectors from different manufacturers on the same zone.



**Caution:** Performing a Sensor Reset momentarily drops power to the devices on Zones 9 and 10. The panel views these zones (9 and 10) as "Open" while the power is absent.

## 11.2 Compatible 2-Wire Smoke Detector Chart

Manufacturer	Model	Detector ID	Base	Base ID	DC Voltage Range	# of Detectors (12V/24V)	Zone Expansion Modules	Panel Zones
Hochiki	SLR-835B-2 SLR-835BH-2	HD-6	N/A		8-35	14	715, 715-8, 715-16	9 & 10
EST	521B, 521BXT, 521NB, 521NBXT	S09A			6.5-20	12	715, 715-8, 715-16	9 & 10
System Sensor	2W-B, 2WT-B	A			8.5-35	10	715, 715-8, 715-16	9 & 10
System Sensor	2WTA-B	A	(*)		8.5-35	12	715, 715-8, 715-16	9 & 10
System Sensor	2WTR-B	A	(*)		8.5-35	1	715, 715-8, 715-16	9 & 10
System Sensor	1151, 2151	A	B110PL, B401		8.5-35	10	715, 715-8, 715-16	9 & 10

(\*) = Must be used in conjunction with System Sensor Polarity Reversal Module model RRS-M0D. See 1.19 for Installation Diagram

Figure 6: Compatible 2-Wire Smoke Detectors

## Dry Contact Relay Outputs

### 12.1 Description

The XR100 Series panel provides two programmable auxiliary SPDT relays when equipped with two DMP Model 305 relays in sockets K6 (Output 1) and K7 (Output 2) and a Model 431 Output Harness on the J2 4-pin Header. Each relay provides one SPDT set of contacts that can be operated by any of the functions listed below:

- |   |                          |
|---|--------------------------|
| 1) Activation by zone condition: Steady, Pulsing, Momentary, and Follow               |                          |
| 2) Activation by 24-hour 7-day schedule: One on and one off time a day for each relay |                          |
| 3) Manual activation from the DMP LCD keypad menu                                     |                          |
| 4) Communication failure  | 8) Exit and Entry timers |
| 5) Armed area annunciation  | 9) System Ready          |
| 6) Fire Alarm or Fire Trouble or Supervisory  | 10) Late to Close        |
| 7) Ambush Alarm   |                          |

Refer to the XR100 Series Canadian Programming Guide (LT-0896CAN) for specific information.

### 12.2 Contact Rating

The Model 305 relay contacts are rated for 1 Amp at 30 Vdc (allows .35 power factor). Connect auxiliary power to the Relay Output 1 common terminal by installing the gray harness wire to terminal 7. Current draw for all connected devices must not exceed the panel maximum current rating.

### 12.3 Model 431 Output Harness Wiring

The relay contacts are accessible by installing the DMP 431 Output Harness on the 4-pin header labeled J2. Output 2 uses the top three prongs, and Output 1 uses the bottom three prongs. The wire harness and contact locations are shown below:

Contact	Color
Output 1 normally closed	Violet
Output 1 common	Gray
Output 1 normally open	Orange
Output 2 normally closed	Violet with white stripe
Output 2 common	White with gray stripe
Output 2 normally open	Orange with white stripe

The relay contacts must be connected to devices located within the same room as the XR100 Series panel.

## Annunciator Outputs

### 13.1 Description

The four programmable annunciator outputs can be programmed to indicate the activity of the panel zones or conditions occurring on the system. Annunciator **outputs do not provide a voltage but instead switch-to-ground** a voltage from another source. The outputs can respond to any of the conditions listed in the Description section for Dry Contact Relays. Maximum voltage is 30 Vdc @ 50mA.

### 13.2 Model 300 Harness Wiring

Access the open collector outputs by installing DMP 300 Harness on the 4-pin header labeled J11. The output locations are shown below. For UL applications, devices connected to the outputs must be located within the same room as the panel.

Output	Color	Wire	Output	Color	Wire
3	Red	1	5	Green	3
4	Yellow	2	6	Black	4

### 13.3 Model 860 Relay Module

Connect a Model 860 Relay Module to the J11 on the XR100 Series Canadian panel to provide relays for outputs 3-6. Use these relays for electrical isolation between the alarm panel and other systems or for switching voltage to control various functions. Power is supplied to the relay coils from a single wire connected to the panel auxiliary power terminal 7. The module includes one relay and provides three additional sockets for expansion of up to four relays. Mount the 860 inside the panel enclosure using the 3-hole pattern and plastic standoffs. Refer to the 860 Module Install Sheet (LT-0484) as needed.

**Relay Contact Rating:** 1 Amp at 30 Vdc (allows .35 power factor)

## J23 6-Pin Header

### 14.1 Description

The XR100 Series Canadian panel supports Direct Programming, LX-Bus, and, DMP Wireless operation. Only one operation can function at a time. Install a jumper on one pair of J23 header pins to indicate how the panel is programmed to operate. Refer to the table below when installing a jumper on J23. When a jumper is installed or moved on the 6-pin header, briefly reset the panel using the J16 jumper to activate the selected operation.

**Note:** Only one operation, Direct Programming, LX-Bus, or DMP Wireless can function at a time.

J23 6-pin Header	
Letter	Operation
R	Direct Programming
L	LX-Bus
X	1100 Series DMP Wireless




Figure 7: J23 6-pin Header

## J22 LX-Bus Expansion Connector

### 15.1 Description

The XR100 Series Canadian panel supports one LX-Bus circuit that provides 100 expansion zones, DMP Wireless that provides 100 wireless zones, or direct connect programming. Enable J22 LX-Bus Header to use the 100 expansion or wireless zones.

### 15.2 J22 LX-Bus Header

**Note:** Only one operation, Direct Programming, LX-Bus, or DMP Wireless can function at a time. See the Connecting LX-Bus and Keypad Bus Devices section for maximum wiring distances.

For each connection, respect wire colors when connecting devices and use all four wires. After placing the jumper on the J23 6-Pin header to enable the required operation, briefly reset the panel using the J16 jumper to activate operation.

**Wireless Bus Operation:** Place a jumper on the two pins next to the letter "X" on the J23 6-Pin header. When using J22 as a wireless bus, connect a DMP Model 300 4-wire Harness to the J22 4-pin header labeled LX. Connect the other end to the J3 header on the 1100X or 1100XH Wireless Receiver. This provides up to 100 wireless zones numbered 500 to 599. Refer to the 1100X Wireless Receiver Install Guide (LT-0708) or the 1100XH Wireless Receiver Install Guide (LT-0970).

**LX-Bus Operation:** Place a jumper on the two pins next to the letter "L" on the J23 6-pin header. When using J22 as an LX-Bus, connect a DMP Model 300 4-wire Harness to the J22 6-pin header labeled LX. This provides 100 LX-Bus zones numbered 500-599.

**Note:** Do NOT use shielded wire when using the LX-Bus.

**Direct Programming Operation:** Place a jumper on the two pins next to the letter "R" on the J23 6-Pin header. When using J22 as a direct programming port, connect a the 4-wire connector from DMP Model 399 Harness to the J22 4-pin header labeled LX. Connect the Model 399 DB-9 connector onto an RS-232 port on a Laptop computer. This allows direct panel programming from the attached computer.

### 15.3 LX-Bus Interface Cards

You can add one Interface Card (Model 481, 462N or 464-263H) to the XR100 Series using J6 Interface Card Connector located on the board right edge. The Interface Cards provide up to 100 LX-Bus Zones. Refer to the following table to identify zone locations and numbers relative to J22 operation.

J22 LX-Bus Enabled (Set J23 to "X")		AND	One Interface Card	
Wireless-Bus	Zone Numbers		LX-Bus	Zone Numbers
1	500-599		1	500-599

### 15.4 LX-Bus LEDs

The two LEDs, located near the bottom-right corner of J21 indicate data transmission and receipt. The top LED flashes green to indicate the panel is transmitting LX-Bus data. The bottom LED flashes yellow to indicate the panel is receiving LX-Bus data.

### 15.5 OVC LED

The Overcurrent LED (OVC) lights Red when the devices connected to the Keypad Bus and LX-Bus(es) draw more current than the panel rating. The OVC is located above Outputs 1 and 2 on the panel and turns a steady Red when lit. When the OVC LED lights Red, the LX-Bus(es) and Keypad bus shut down.



## J1 Ethernet Connector (XR100N only)

### 16.1 Description

The J1 Ethernet Connector is available on the XR100N Network version to connect directly to an Ethernet network using a standard patch cable. The maximum line impedance is 100 Ohms.

### 16.2 Ethernet LEDs

The two LEDs, located to the left of J1 Ethernet Connector, indicate network connection. The top, Link LED lights up green to indicate a valid receive connection from the host network. The bottom, Activity LED flashes yellow to indicate messages are being sent and received.




Figure 8: J1 Header and LEDs

## J3 Telephone RJ Connector

### 17.1 Description

Connect the panel to the public telephone network by installing a DMP 356 RJ Cable between the panel J3 connector and the RJ31X or RJ38X phone jack. The maximum line impedance is 100 Ohms. **CAUTION** - To reduce the risk of fire, use only No. 26 AWG or larger telecommunication line cord, such as DMP Model 356 Series Phone Cords.

### 17.2 J10 893A Connector

Connect an 893A Dual Phone Line Module to J10 on the XR100 Series. Refer to the 893A Installation Sheet (LT-0135) for complete information.

### 17.3 Notification

The user must not repair registered terminal equipment. In case of trouble, immediately unplug the device from the telephone jack. The factory warranty provides for repairs. Registered terminal equipment may not be used on party lines or in connection with coin telephones. Notify the telephone company with the following information:

- The particular line(s) where the service is connected
- This Class A digital apparatus complies with Canadian ICES-003.
- The ringer equivalence
- The device make, model, and serial number

### 17.4 Phone Line Monitor

The XR100 Series panel has a built-in telephone monitor that monitors the phone line voltage to verify the connection to the central office. Figure 9 and the table below identify the phone block pin layout, wire numbers, and colors.

Wire Number	Wire Color
1	Gray
2	Orange
3	Black
4	Red
5	Green
6	Yellow
7	Blue
8	Brown




Figure 9: Phone Jack Wiring

The wires on the RJ31 that feed pins 4 and 5 should be the ONLY wires on the D-marc. All other house phone wiring should be tied to pins 1 and 8 coming back from the RJ31.

Dial tone must come into RJ31X on pins 4 and 5 and go back to house phones from pins 1 and 8. Follow these steps to determine if panel is seizing the line:

- Unplug phone cord from RJ31X
- Place butt-set on pins 4 and 5
- Listen for dial tone. With dial tone present, lift either wire from pins 1 or 8
- Listen for dial tone again. If the dial tone is present, RJ31X wiring is correct. If no dial tone is present, the RJ31X wiring is backwards. Rewire so dial tone is coming IN on 4 and 5.

If you still have trouble with the phone line, you may need to replace the RJ cord. If the dial tone is still not present, swap out the RJ31X phone block.



## Reset and Tamper Headers

### 18.1 J16 Reset Header

The reset header is located just above the terminal strip on the right side of the circuit board and is used to reset the XR100 Series microprocessor. To reset the panel when first installing the system, install the reset jumper before applying power to the panel. After connecting the AC and battery, remove the reset jumper.

To reset the panel while the system is operational, for example, prior to reprogramming, install the reset jumper without powering down the system. Remove the reset jumper after one or two seconds.

After resetting the panel, begin programming within 30 minutes. If you wait longer than 30 minutes, you must reset the panel again.




Figure 10: XR100 Series Canadian Panel Showing the Reset Jumper

### 18.2 J4 Tamper Header

The J4 header is for use with the optional DMP 306 Tamper Harness. The harness connects to one or more tamper switches mounted inside the panel enclosure to supervise against unauthorized enclosure opening or removal. Refer to the wiring diagram on the enclosure door for correct tamper switch wiring.

#### How the Tamper Works

If the enclosure is opened or removed while one or more of the system areas are armed, a panel tamper alarm is indicated. If all areas are disarmed, a panel tamper trouble is indicated.

## Listed Compliance Specifications

### 19.1 Introduction

For applications that must conform to a local authorities installation standard or a National Recognized Testing Laboratory certificated system, please see the following sections.

## Burglary Specifications

### 20.1 Introduction

The programming and installation specifications contained in this section must be completed when installing the XR100 Series Canadian panel in accordance with any of the burglary standards. Additional specifications may be required by a particular standard. See the XR100 Series Canadian Programming Guide (LT-0896CAN).

### 20.2 Control Outside of Protected Area

A Potter EVD or Sentrol 5402 must be used when the panel is installed outside of the vault in a financial application. Front and rear tamper switches are required. Refer to the system wiring diagram.

### 20.3 Bypass Reports

The Bypass Reports option must be programmed as YES for all burglary applications.

### 20.4 System Maintenance

To ensure continuous satisfactory operation of any alarm system, proper installation and regular maintenance by the installing alarm company and frequent testing by the end user is essential. Offering a maintenance program and acquainting the user with the correct procedures for system use and testing is also the responsibility of the installing alarm company.

## ULC S304-06 Specifications

Signal Receiving Center and Premise Burglar Alarm Control Units

### 21.1 For Low Risk Applications: Level A1

Level A1 communication channel security is provided for Internet, Intranet, LAN or WAN networks when configured as a NET communicating system using the XR100N.

NET:	
PRIMARY	
SUB CODE:	YES
CHECKIN TIME:	2 MINUTES
FAIL TIME:	3 MINUTES
SEND COMM TRBL:	YES
TCP COMM:	YES

### 21.2 For Low Risk Applications: Level P1

Level P1 communication channel security is provided when configured as a DD communicating system and a daily test message using the XR100.

### 21.3 Dual Protection

For Medium or High Risk ULC Listed Applications: Use only zones 1-8 on the control panel and program Dual EOL as Yes in panel programming. Program the Disarmed Short Message in Alarm Action of Zone Information programming as a Trouble message.

Note: If using a 714, 714-8, or 714-16 for dual protection, program two zones as the same name or equivalent and connect to the contact in the protected area as show in the Dual Zone Protection diagram in the back of this guide.

### 21.4 Remote Arming

For ULC Listed applications, remote arming is not permitted.

### 21.5 Zone Expansion

Use of the following zone expanders are permitted for connection of burglary devices:

710 Bus Splitter Module	714 Zone Expander, 4 zones	715 Zone Expander, 4 zones	7070(A)/7073(A) Keypads, 4 zones
711 Zone Expander, Single	714-8 Zone Expander, 8 zones	715-8 Zone Expander, 8 zones	7170/7173 Keypads, 4 zones
712-8 Zone Expander, 8	714-16 Zone Expander, 16 zones	715-16 Zone Expander, 16 zones	

## ULC S559-04 Specifications

Equipment for Fire Signal Receiving Centers and Systems

### 22.1 For Fire Communicator Applications

For fire communicator applications, communication to the fire signal receiving center is provided for Internet, Intranet, LAN or WAN networks when configured as a NET or CELL communicating system using the XR100 Series panel. See wiring diagram in section 25.4 for additional information. Program one of the following options in panel Communication:

#### Path 1 Type NET or CELL Primary with no Backup

Path 1 Programming	
Comm Type = NET or CELL	Checkin Min = 3
Path Type = Primary	Failtime Min = 3
Sub Code = No	Send Comm Trbl = Yes
Comm Path Trbl = Yes (Status List Programming)	

#### Path 1 Type NET Primary and Path 2 Type CELL Backup

Path 1 Programming	Path 2 Programming
Comm Type = NET	Comm Type = CELL
Path Type = Primary	Path Type = Backup
Test Rpt = Yes	Test Rpt = Yes
Test Freq = 1 Dy	Test Freq = 1 Dy
Send Comm Trbl = Yes	Send Comm Trbl = Yes
Comm Path Trbl = Yes (Status List Programming)	

### 22.2 Central Station Host Automation

The fire signal receiving center's host automation system must recognize the following signals: Zone 1 Alarm = Fire Alarm, Zone 2 Trouble = Fire Zone Trouble, Zone 3 Trouble = AC Trouble, Zone 4 Trouble = Battery Trouble, and Zone 5 Trouble = Ground Fault Trouble.

## Recommendations

### 23.1 ULC Installation Recommendations

1. In order to give the digital alarm communicator transmitter the ability to disconnect an incoming call to the protected premises, telephone service should be of the type that provides for timed release disconnect.
2. Network access and domain access policies shall be set to restrict unauthorized network access and "spoofing" or "denial of service" attacks.
3. Select Internet Service Providers that have redundant servers/systems, Back-up power, Routers with Firewall enabled and Methods to identify and protect against "Denial of Service" attacks (i.e. via "spoofing").
4. Power for network equipment as hubs, switches, routers, servers, modems, etc., shall be backed up or powered by an un-interruptible power supply (UPS), stand-by battery or the control unit, capable of facilitating 24 hour standby, compliant with Clauses 16.1.2 and 16.4.1 of CAN/ULC-S304-06.
5. Where such cannot be facilitated, the control unit shall support back-up communications for a secondary communications path, subject to the following:
  - Low Risk and Medium Risk shall use a dialer as a minimum;
  - High Risk shall use cellular control channel or long range radio as a minimum; and
  - Very High Risk shall be equipped with 24 hour standby power. Note: Refer to Table 11 of CAN/ULC-S304-06 for the risk levels.
6. Refer to CAN/ULC-S302, Installation and Classification of Burglar Alarm Systems for Financial and Commercial Premises, Safes and Vaults, for requirements for a secondary communications path, where 24 hour standby cannot be facilitated for all communications interface components as routers, hubs, switches and other network components.
7. Products or components of products used in communication channels, which perform communications functions only, shall comply with the requirements applicable to communications equipment as specified in CAN/CSA-C22.2 No. 60950-1, Information Technology Equipment-Safety - Part 1: General Requirements. Such products or components include, but are not limited to:
  - A Hubs;
  - B Routers;
  - C Network interface devices;
  - D Third party communications service providers;
  - E Digital subscriber line (DSL) modems; and
  - F Cable modems

## False Alarm Reduction Programmable Options \*

### 24.1 Shipping Defaults and Recommended Programming for ANSI/SIA CP-01-2010

SIA CP-01 FEATURE PARAGRAPH # AND DESCRIPTION	DMP XR100 SERIES PROGRAMMING GUIDE LT-0896 SECTION #	REQUIREMENT	RANGE	SHIPPING DEFAULT	RECOMMENDED PROGRAMMING*
4.2.2.1 Exit Time	14.2 Exit Delay	Required (Programmable)	45 sec. - 250 sec.	60 Seconds	60 Seconds
4.2.2.2 Progress Annunciation	14.2 Exit Delay	Allowed	Individual keypads may be disabled per zone	All keypads enabled	All keypads enabled
4.2.2.3 Exit Time Restart	14.2 Exit Delay	Required Option	For re-entry during exit time	Enabled	Enabled
4.2.2.5 Auto Stay Arm on Unvacated Premises	32.3 Occupied Premise - See XR100 Series Program Guide (LT-0896CAN)	Required Option (except for remote arming)	Area 1 = Perimeter Area 2 = Interior	Enabled	Enabled for Residential Applications
4.2.4.4 Exit Time and Progress Annunciation/ Disable - for Remote Arm	Not Available on Remote Arming	Allowed Option	Progress Annunciation Always disabled for Remote Arming	Not Available	Remote Arming not allowed for CP-01 installations.
4.2.3.1 Entry Delay(s)	8.3 Entry Delay	Required (Programmable)	30 sec. - 240 Sec. **	30 Seconds	At least 30 Seconds **
4.2.5.1 Abort Window - for Non-Fire Zones	3.7 Transmit Delay	Required Option	Disable by zone or zone type	Enabled NT DY EX Zone	Enabled
4.2.5.1 Abort Window Time - for Non-Fire Zones	3.7 Transmit Delay	Required (Programmable)	15 sec. - 45 sec. **	30 Seconds	At least 15 Seconds **
4.2.5.1.2 Abort Annunciation	3.7 Transmit Delay	Required Option	Annunciate that no alarm was transmitted (\$45)	Yes	Yes
4.2.5.4.1 Cancel Annunciation	Always Enabled - Not Programmable	Required Option	Annunciate that a Cancel was transmitted (\$49)	Always Enabled	Yes
4.2.6.1 & 4.2.6.2 Duress Feature	User Code + 1 = Ambush Code Not Available	Allowed Option	No 1 + derivative of another user code/no duplicates with other user codes	Code +1 Always Disabled	Not Programmable
4.3.1 Cross Zoning	15.21 Cross Zone	Required Option	Yes/No Zone Programming	No	Enabled using two or more programmed zones
4.3.1 Programmable Cross Zoning Time	8.4 Cross Zone Time	Allowed	4 sec. - 250 sec.	4 Seconds	Per walk path in protected premises
4.3.2 Swinger Shutdown	8.7 Swinger Bypass Trips	Required (Programmable)	For all non-fire zones, shut down at 1 or 2 trips	One (1) trip	One (1) trip
4.3.2 Swinger Shutdown Disable	15.15 Swinger Bypass	Allowed	For non-police response zones	Yes	Enabled (all zones)
4.3.3 Fire Alarm Verification	15.4 Zone Type	Required Option	FV Type Zone	No	Yes as required (unless sensors can self verify)
4.5 Call Waiting Cancel	3.19 Telephone Number	Required Option	Include *70P in Telephone Number	Disabled	Enabled if user has call waiting

\* Programming at installation may be subordinate to other UL requirements for the intended application.

\*\* For listed installations, combined Entry Delay and Transmit Delay should not exceed 1 minute.

## False Alarm Reduction Programmable Options (continued)

### 24.2 Call Waiting (ANSI/SIA CP-01-2010)

The Call Waiting default setting is disabled. To cancel the Call Waiting feature, program \* (star) 7 0 P (pause), the standard telephone code prefix that cancels call waiting, into the telephone number string. Cancel Call Waiting for telephone lines that have Call Waiting operational on the telephone line. See the XR100 Series Canadian Programming Guide (LT-0896CAN).



**Caution:** A call waiting cancel programmed on a non-call waiting telephone line, would prevent communication to the central station.

### 24.3 Occupied Premise (ANSI/SIA CP-01-2010)

When only two areas are used, and area one is named Perimeter, and area two is named Interior, and no exit type zone transition occurs during the exit delay because the premise continues to be occupied, the Interior area will automatically disarm at the end of the exit delay.

### 24.4 Entry Delay (ANSI/SIA CP-01-2010)

Only use Entry Delay 1. Do not use Entry Delay 2, 3, or 4. See the XR100 Series Canadian Programming Guide (LT-0896CAN).


### 24.5 Minimum Installation Requirements (ANSI/SIA CP-01-2010)

SIA CP-01-2010 minimum system installation requirements include an XR100 Series, a listed local Bell, and off premise DACT communication to an SCS-1R receiver plus one of the following compatible keypads.


- 630F Fire Command™ Center
- 7060, 7063, 7070, or 7073 Thinline™ keypads
- 7060A, 7063A, 7070A, or 7073A Aqualite™ keypads
- 7160, 7163, 7170, or 7173 Thinline™ keypads

## Wiring Diagrams


### 25.1 LX-Bus™ Module Connection




## 25.2 Model 860 Relay Module Connection



## 25.3 Dual Zone Protection




## 25.4 Canadian Fire Communicator for FACP






## 25.5 Combination S304 and S559 System



## 25.6 System Sensor 2-Wire Smoke Detectors



## Revisions to This Document

This section explains the changes that were made to this document during this revision. This section lists the date the change was made, the section number and heading, and a quick summary of the change.

Ver.	Section Number and Heading	Summary of Changes
1.20	1.5 LX-Bus	Added Model 2W-BLX and 2WT-BLX Smoke Detector references
	3.4 Accessory Devices	Added Model 2W-BLX and 2WT-BLX Smoke Detector references
	6.8 XR100 Series Canadian Power Requirements	Added Model 2W-BLX and 2WT-BLX Smoke Detector references
1.19	Complete Guide	Added 464 Series references
	3.4 Accessory Devices	Updated for current products
	6.8 XR100 Series Canadian Power Requirements	Updated for current products
1.18	6.1 Battery Terminal 3 and 4	Updating model 368
	6.9 Standby Battery Selection	Updating model 368
1.17	Entire Document	Removed 463C references
	25.1 LX-Bus Module Connection	Updated diagram and added DMP Interface Cards
1.16	1.7 Enclosure Specifications	Added 341 Enclosure
	4.1 Mounting the Enclosure	Added 341 diagram

## Certifications

This Class A digital apparatus complies with  
Canadian ICES-003

ANSI/SIA CP-01-2010 False Alarm Reduction

ULC-S559-04 Equipment for Fire Signal  
Receiving Centers and  
Systems

ULC S545 Household Fire

ULC Subject-C1023 Household Burglar

ULC/ORD-C1076 Proprietary Burglar

ULC S304 Central Station Burglar



800-641-4282

[www.dmp.com](http://www.dmp.com)

Designed, Engineered and  
Assembled in USA

INTRUSION • FIRE • ACCESS • NETWORKS

2500 North Partnership Boulevard

Springfield, Missouri 65803-8877

LT-0899CAN 1.21 © 2015 Digital Monitoring Products, Inc.



15135